



Premium Building Products
That Protect

Protecto-Tak Spray Adhesive

DESCRIPTION

- Recommended For Use With All Protecto Wrap Window Flashing Tapes, Sill Sealing Tapes, Waterproofing Membranes and Air Vapor Barrier Membranes
- Can Be Applied Over Concrete, Wood, OSB, Vinyl, Plywood, Metal, Aluminum, Polyethylene, Building Wraps, Dens-Glass® Gold, Block and Masonry Surfaces
- Excellent Water and Temperature Resistance
- Does Not Contain Methylene Chloride Or Ozone Depleting Chemicals
- VOC Compliant
- For Industrial Use Only

DIRECTIONS

1. Surface to be treated should be dry, clean and free of any dirt, dust or foreign matter that may adversely affect adhesion.
2. Shake can well before use. Align spray tip to black dot on can.
3. Direct arrow and spray toward surface to be treated (holding can 6" from substrate) and apply a uniform coat of adhesive.
4. Allow treated surface to dry for about 2 minutes (no more than 10 minutes) before applying Protecto Wrap membrane.
5. Do not cover wet Protecto-Tak.

To prevent clogging after each use, invert container and spray until nozzle clears. If clogging does occur, clean tip and valve with hot water. High humidity and heavy coverage of adhesive will slow evaporation rate of solvent. Under these conditions, allow maximum drying time before applying Protecto Wrap waterproofing membranes. Clean up with soap and water.

CAUTION

Flammable, do not smoke when using product. Harmful or fatal if swallowed. Contents under pressure. Wear safety glasses and gloves when using product. Read Material Safety Data Sheet (MSDS) before using and see product packaging for additional safety information.

PACKAGING

13 oz. can (369 grams)/12 cans per case



Protecto Wrap Company
(800) 759-9727
www.protectowrap.com