



1. Visit [Protectowrap.com](http://Protectowrap.com) for the most current information
2. Refer to Technical Data sheet for more information
3. The drip edge should be installed over the first layer of Protecto Wrap Underlayment
4. The second layer of Protecto Wrap Underlayment should be installed over the drip edge
5. Protecto Wrap Underlayments should be installed to form water-shedding laps
6. Edge laps are minimum 2" and end laps are minimum 6"-  
Refer to Technical Data Sheet for Product specific requirements
7. Repair all holes or damage from the removal of Toe boards, roof jacks, etc. prior to the final application fo exposed roof covering

**EAVE OPTION  
WITH DRIP EDGE STRIPPED IN**



**EFFECTIVE DATE: 01/07/10**  
**SUPERSEDES: 07/07/09**  
**SCALE: NOT TO SCALE**  
**DRAWING: PW401**