



1. Visit Protectowrap.com for the most current information
2. Refer to Technical Data sheet for more information
3. Protecto Wrap Underlayments should be installed to form water-shedding laps
4. Edge laps are minimum 2" and end laps are minimum 6"- Refer to Technical Data Sheet for Product specific requirements
5. Install Protecto Wrap Underlayment, Detail Tape, and JS 160 H Mastic, in order shown
6. Extend Protecto Wrap Underlayment from eave to below Skylight, and from above Skylight to ridge
7. Install Skylight, flashing, and roof covering per Manufacturers recommendation
8. Determine if Skylight materials (gasket, flashing, etc.) are compatible with Protecto Wrap Underlayments

SKYLIGHT



EFFECTIVE DATE: 01/07/10

SUPERSEDES: 07/07/09

SCALE: NOT TO SCALE

DRAWING: PW403