



1. Visit [Protectowrap.com](http://Protectowrap.com) for the most current information
2. Refer to Technical Data sheet for more information
3. Install Protecto Wrap products in order shown
4. Check local building codes for weather resistive barrier requirements and install Protecto Wrap Products to form water-shedding laps
5. If applicable, leave release paper on lower half of sill flashing, for future tie-in to the Weather Resistive Barrier
6. Bead of sealant across sill, and up jambs 6"; can be replaced with low pressure, minimal expansion foam, if required by Window manufacturers instructions
7. Sealant used shall be compatible with Protecto Wrap membranes, see Technical Letter "Chemical Compatibility" for more information

**FLANGED WINDOW  
PROTECTO WRAP**



EFFECTIVE DATE: 01/08/10  
 SUPERSEDES: 09/03/09  
 SCALE: NOT TO SCALE  
 DRAWING: PW601