



1. Visit Protectowrap.com for the most current information
2. Refer to Technical Data sheet for more information
3. Extend Protecto Wrap Underlayment on the wall sheathing above the highest expected level of snow and ice
3. Extend Protecto Wrap Underlayment on the roof deck above the highest expected level of water back-up from ice dams ②
4. Extend Protecto Wrap Underlayment beyond eave onto vertical side wall ①
5. The metal flashing is installed over the Protecto Wrap Underlayment
6. Install Protecto Wrap Underlayment in order as shown by numbers
7. Protecto Wrap Underlayments should be installed to form water-shedding laps
8. Edge laps are minimum 2" and end laps are minimum 6"-
Refer to Technical Data Sheet for Product specific requirements

VERTICAL SIDE WALL



EFFECTIVE DATE: 01/07/10
 SUPERSEDES: 07/07/09
 SCALE: NOT TO SCALE
 DRAWING: PW405